

Carolina Security Easy As 1-2-3

When Exiting Arming: The Lock Symbol.
This operation is the same as pressing "Exit" on the keypad

To Disarm: Press the Unlock Symbol "Off"


Night Time Arming: Press "Light Bulb" Symbol (remember: night-light) Press again for instant alarming (doors have no delay for burglars) This operation is the same as pressing "Stay" on the keypad
NOW INTERIOR MOTIONS ARE BYPASSED. SYSTEM IS ARMED.

Your alarm has three settings: "Exit" mode, "Stay" mode, and "Off" mode.

Silent Panic Alarm: Press the Lock Symbol and the Unlock Symbol at the same time.



NX-470



Indicator light:
Flashes when a button is pressed

Unless programmed otherwise, the star button will arm the alarm without blasting the sirens.

Remember: When pressing a button it is necessary to hold the button down for one (1) second for signal to be sent. This feature avoids unintentional operations from remote.